



## **Functions**

\*Standard Philips RC5 protocol

	Function	RC5
1	Power	50
2	Volume up	51
3	Volume down	52
4	Move left	55
5	Move right	54
6	Mute	53
7	Function 1	56
8	Function 2	57
9	Function 3	59
10	Function 4	61
11	Select	48
	Device code	16

## Installation

- Take off the battery cap
- Place a Cr2023 battery with the '+' as in picture
- Put back the battery cap





contact with clip A

## Warranty

The work carries warranty out for all provable material and production defects for the duration of 12 months starting from sales. All damage, which is caused by wrong or inappropriate operation, is excluded from the warranty.

For technical matters or questions about the functionality of this product please contact:

support@hypex.nl www.hypex.nl



